

Запасные части для упаковочного оборудования

Перечень

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Калининград (4012)72-03-81	Омск (3812)21-46-40	Сыктывкар (8212)25-95-17
Ангарск (3955)60-70-56	Калуга (4842)92-23-67	Орел (4862)44-53-42	Тамбов (4752)50-40-97
Архангельск (8182)63-90-72	Кемерово (3842)65-04-62	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Киров (8332)68-02-04	Пенза (8412)22-31-16	Тольятти (8482)63-91-07
Барнаул (3852)73-04-60	Коломна (4966)23-41-49	Петрозаводск (8142)55-98-37	Томск (3822)98-41-53
Белгород (4722)40-23-64	Кострома (4942)77-07-48	Псков (8112)59-10-37	Тула (4872)33-79-87
Благовещенск (4162)22-76-07	Краснодар (861)203-40-90	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Красноярск (391)204-63-61	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Курск (4712)77-13-04	Рязань (4912)46-61-64	Улан-Удэ (3012)59-97-51
Владикавказ (8672)28-90-48	Курган (3522)50-90-47	Самара (846)206-03-16	Уфа (347)229-48-12
Владимир (4922)49-43-18	Липецк (4742)52-20-81	Саранск (8342)22-96-24	Хабаровск (4212)92-98-04
Волгоград (844)278-03-48	Магнитогорск (3519)55-03-13	Санкт-Петербург (812)309-46-40	Чебоксары (8352)28-53-07
Вологда (8172)26-41-59	Москва (495)268-04-70	Саратов (845)249-38-78	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Мурманск (8152)59-64-93	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Набережные Челны (8552)20-53-41	Симферополь (3652)67-13-56	Чита (3022)38-34-83
Иваново (4932)77-34-06	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54	Якутск (4112)23-90-97
Ижевск (3412)26-03-58	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31	Ярославль (4852)69-52-93
Иркутск (395)279-98-46	Ноябрьск (3496)41-32-12	Ставрополь (8652)20-65-13	
Казань (843)206-01-48	Новосибирск (383)227-86-73	Сургут (3462)77-98-35	
Россия +7(495)268-04-70	Киргизия +996(312)-96-26-47	Казахстан +7(7172)727-132	

Bagging Scale



941248187 Rod Eyes FES-9262 SGS-M12*1.25



941278487 Swivel Flange FES-174393 SNCB-63



941279387 Swivel Flange FES-174391 SNCB-40



94160187 Load Cell 100 kg GS-2A With Cable



94168287 Taper Bush 2517 Ø40 For Feed Screw




94271787 Pneumatic Piston FES-1383581 DSBC-63-80 PPVA-N3



9440070987 Pneumatic Piston FES-1366954 DSBC-50-160-PPV-A-N3 SILINDIR



945801087 Single Coil Solenoid Valve FES-575249



945802087 Solenoid Coil VACS-C-C1-1 24 Volt FES-8025330



945802187 Plug Socket MSSD-EB-M12 FES-539712



945814687 Bearing Housing UCFC 208 FYC For Feed Screw




945830087 FES-529156 Filter Regulator MS4-LFR-1/4-D7-ERM-AS



946191887 Taper Bush 2517 Ø35 For Feed Screw




946358887 Taper Bush 1108 Ø24



9477087 Rod Clevis SG-M16X1,5 FES-6146



9491334487 Pneumatic Piston FES-1376658 DSBC-40-50-PPVA-N3




9491443387 V Belt 13*1250



9491445587 Taper Bush 1610 Ø28 For Feed Screw



9491521587 Feed Screw Distributor DM-BH-0848-00




9491521687 V Belt 13*1275



9491521787 Feed Screw Clutch Flange DM-BH-0868-00




9491521887 Bearing Housing UCFC 209 FK For Feed Screw




9491521987 Pulley SPA 100*2 For Feed Screw




9491522087 Pulley SPA 240*2



9491522187 Pulley SPA 280*2 For Feed Screw



9491522387 Pulley SPA 250-2



9491522487 Pulley SPA 75-2

Vibro Discharger



941275187 Vibro Discharger Sleeve Q60



941275287 Vibro Discharger Sleeve Q100



941281687 Vibro Discharger Sleeve Q250



94160887 Vibro Motor Mve 0.35 kW 1000 Rpm Discharger 160



94160987 Vibro Motor 0.75 kW 1000 rpm Discharger 200



94177887 Vibro Motor 0.16 kW 1500 rpm MVE-200-15 Discharger 60-100



94199187 Tensioning Straps For Rotoflow 100 (3500 mm) Discharger 100



94199387 Tensioning Straps For Rotoflow 60 (2000 mm) MVD 60



94199487 Tensioning Straps For Rotoflow 160 (5500 mm) Discharger 160



94199587 Tensioning Straps For Rotoflow 200 (6500 mm) Discharger 200



9430218887 Vibro Discharger Sleeve Q200



9430218987 Vibro Discharger Sleeve Q160



943412387 Plastic Covered Link Rod For Vibro Discharger 160-100-200



943427487 Body Connecting Rod Discharger 150-120



943427687 Plastic Covered Link Rod 25mm Discharger 60

Redressing Sifter



941209487 Spring Clips Top Outlet Jumbo Q1*4.5*450



941209587 Spring Clips Top Inlet Jumbo Q1*4.5*700



94131287 Filter Bottom Outlet Sleeve Jumbo Q150*350



94131387 Filter Top Inlet Sleeve Jumbo Q250*350



94133987 Adhesive



94134187 Sieve Glue For Wooden Insert Frames



94134687 Strip For Sieve Boxes 10 Mm




94134787 Strip For Sieve Boxes 16 Mm




94136987 Drop Sieve Cleaner




94137087 Cotton Sieve Cleaner



94137387 Plansifter Nylon Sieve Nytal PAXXX 1320 mm



94137587 Plansifter Nylon Sieve Nytal PAGG 1320 mm



94138087 Bottom Stripper



94138887 Fiber Sieve Rods Q12*4000




94138987 Wire Mesh for Plansifter Insert Frame Q1,6 10*10



94139787 Fiber Sieve Rods Q16*4000



94154187 Seal Q70*Q90*10



94154287 V-Belt 13*2200



94154487 Motor 1.5 kW 1000 rpm AGM 100 L




94154787 Wedge A Type 10*8*20




94195187 Rubber Cover Q100



9430234587 Clamp Lower Output Ø115-135mm



94778087 Clamps for Plansifter Toolbar



94866687 Check Box KN Type 70 Double



94874787 Sieve Frame Roving Felt



9491090487 Motor 2.2 kW 1000 rpm AGM 112 M B3



9491178887 Silicon Mastic 280ml White

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231	Калининград (4012)72-03-81	Омск (3812)21-46-40	Сыктывкар (8212)25-95-17
Ангарск (3955)60-70-56	Калуга (4842)92-23-67	Орел (4862)44-53-42	Тамбов (4752)50-40-97
Архангельск (8182)63-90-72	Кемерово (3842)65-04-62	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Киров (8332)68-02-04	Пенза (8412)22-31-16	Тольятти (8482)63-91-07
Барнаул (3852)73-04-60	Коломна (4966)23-41-49	Петрозаводск (8142)55-98-37	Томск (3822)98-41-53
Белгород (4722)40-23-64	Кострома (4942)77-07-48	Псков (8112)59-10-37	Тула (4872)33-79-87
Благовещенск (4162)22-76-07	Краснодар (861)203-40-90	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Красноярск (391)204-63-61	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Курск (4712)77-13-04	Рязань (4912)46-61-64	Улан-Удэ (3012)59-97-51
Владикавказ (8672)28-90-48	Курган (3522)50-90-47	Самара (846)206-03-16	Уфа (347)229-48-12
Владимир (4922)49-43-18	Липецк (4742)52-20-81	Саранск (8342)22-96-24	Хабаровск (4212)92-98-04
Волгоград (844)278-03-48	Магнитогорск (3519)55-03-13	Санкт-Петербург (812)309-46-40	Чебоксары (8352)28-53-07
Вологда (8172)26-41-59	Москва (495)268-04-70	Саратов (845)249-38-78	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Мурманск (8152)59-64-93	Севастополь (8692)22-31-93	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Набережные Челны (8552)20-53-41	Симферополь (3652)67-13-56	Чита (3022)38-34-83
Иваново (4932)77-34-06	Нижний Новгород (831)429-08-12	Смоленск (4812)29-41-54	Якутск (4112)23-90-97
Ижевск (3412)26-03-58	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31	Ярославль (4852)69-52-93
Иркутск (395)279-98-46	Ноябрьск (3496)41-32-12	Ставрополь (8652)20-65-13	
Казань (843)206-01-48	Новосибирск (383)227-86-73	Сургут (3462)77-98-35	
Россия +7(495)268-04-70	Киргизия +996(312)-96-26-47	Казахстан +7(7172)727-132	